

## Why is the Lovense icon flashing yellow in my live room?

Last Modified on 07/31/2020 1:31 pm EDT

If the Lovense icon is flashing yellow in the top of your live room, it means that one of your toys is disconnected or low on batteries. Make sure to fully charge your toys if you are experiencing any connection issues.

If your Lovense Connect app shows a weak connection for your toy, [try these tips!](#)

If your Lovense toy is disconnecting from MV Live, [click here!](#)

